


**RYOBI**  
**COMPACT FINISHING SANDER**  
**MODEL NO. CFS1501**  
**REPAIR SHEET**

## RYOBI FINISHING SANDER – MODEL NUMBER CFS1501

The model number will be found on a plate attached to the motor housing. Always mention the model number in all correspondence regarding your **FINISHING SANDER** or when ordering repair parts.



### PARTS LIST

| KEY NO. | PART NUMBER | DESCRIPTION                | QTY. |
|---------|-------------|----------------------------|------|
| 1       | CFS1501-31  | DUST BAG .....             | 1    |
| 2       | CFS1501-32  | PUNCHER.....               | 1    |
| 3       | CFS1501-33  | SANDPAPER, (60 GRIT).....  | 2    |
| 4       | CFS1501-34  | SANDPAPER, (120 GRIT)..... | 3    |
| 5       | CFS1501-35  | SANDPAPER, (240 GRIT)..... | 2    |
| 6       | CFS1501-36  | SCRUB, HEAVY .....         | 1    |
| 7       | CFS1501-37  | SCRUB, LIGHT.....          | 1    |
| 8       | CFS1501-38  | SCRUB, POLISHING.....      | 1    |
|         | 983000-367  | OPERATOR'S MANUAL          |      |
|         | 983000-367R | REPAIR SHEET               |      |
|         | 01-15-04    |                            |      |