

## RYOBI RECIPROCATING SAW – MODEL NUMBER RJ150

The model number will be found on a plate attached to the motor housing. Always mention the model number in all correspondence regarding your **RECIPROCATING SAW** or when ordering repair parts.

### PARTS LIST

Key No.	Part Number	Description	Quan.	Key No.	Part Number	Description	Quan.
1	969274-009	CORD .....	1	32	998743-001	SET SCREW (#5/16-24) .....	1
2	968303-097	SWITCH .....	1	33	940021-008	CAP SCREW (#10-24 X 5/8 IN. SOC. HD.) .....	1
3	617966-028	SCREW (#8-10 X 1/2 IN. PAN HD.) .....	1	34	623934-002	BLADE SCREW .....	1
4	617966-030	SCREW (#8-10 X 5/8 IN. PAN HD.) .....	10	35	607353-001	BLADE CLAMP ASSEMBLY .....	1
5	973703-001	LOGO PLATE .....	1	36	974134-001	BLADE .....	1
6	617966-017	SCREW (#8-10 X 1-1/4 IN. PAN HD.) .....	1	37	973808-002	BASE ASSEMBLY .....	1
7	973729-000	HOUSING ASSEMBLY .....	1	38	974040-001	RUBBER BOOT .....	1
8	623552-001	STATOR PAD .....	1	39	706404-007	HEX NUT (#8-32) .....	4
9	885883-028	GROMMET .....	1	40	973704-001	DATA PLATE .....	1
10	606124-007	SCREW (#6-20 X 1/2 IN. PAN HD. T.F.) .....	2	41	998280-002	GEAR SUPPORT FRAME .....	1
11	706239-830	WASHER .....	2	42	941401-812	ROLL PIN .....	2
12	617401-001	THRUST BEARING .....	1	43	623281-006	HEX NUT (#3/8-24) .....	1
13	614658-041	SCREW (#8-32 X 1-5/16 IN. PAN HD.) .....	4	44	931055-825	WASHER .....	1
14	622170-003	SPRING WASHER .....	4	45	999970-004	SHAFT .....	1
15	612801-005	ROLLER BEARING .....	2	46	998307-001	SET SCREW (#10-24 X 1/2 IN.) .....	1
16	999969-001	GEAR ASSEMBLY (INCLUDES KEY NO. 15) ...	1	47	968305-027	BALL BEARING (NTN#6200LLBC3/1E) .....	1
17	622347-008	WASHER .....	1	48	622167-017	RETAINING RING .....	1
18	706382-812	WASHER .....	1	49	968306-078	ARMATURE ASSEMBLY (INCLUDES KEY NOS. 47, 48, AND 50) .....	1
19	622167-067	RETAINING RING .....	1	50	968305-010	BALL BEARING (NTN#608ZZC3/1E) .....	1
20	968305-033	BALL BEARING (NTN#6200LBZC3/1E) .....	1	51	998408-001	BEARING STRAP .....	1
21	999963-001	GEAR ASSEMBLY (INCLUDES KEY NOS. 22 AND 23) .....	1	52	968307-116	FIELD ASSEMBLY .....	1
22	999964-001	SLEEVE BEARING .....	1	53	968304-058	BRUSH ASSEMBLY .....	1
23	607352-001	CROSS SLIDE PIN .....	1	54	611967-001	BRUSH TUBE .....	2
24	607351-001	CROSS SLIDE ROLLER .....	1	55	968775-001	SCREW (M3 X 7 FIL. HD.) .....	2
25	999893-001	SAW BAR ASSEMBLY .....	1	56	999348-001	GEAR TRAIN ASSEMBLY (INCLUDES KEY NOS. 11, 12, 15-23, 30, 31 AND 41-46) .....	1
26	621431-009	SCREW (#10-24 X 3/4 IN. FIL. HD.) .....	2	57	820193-006	HEX KEY (#5/32) .....	1
27	999968-002	BEARING .....	1	58	973728-000	CARRYING CASE .....	1
28	999297-001	FELT WICK .....	1	59	620801-001	SLEEVING .....	1
29	999298-001	SAW BAR PLATE .....	1		972000-245	OWNER'S MANUAL	
30	999922-002	SHAFT .....	1		2-99		
31	941401-021	ROLL PIN .....	1				